

## Temporary Strainers SS316L DIMENSIONS

### Fits between Din and ANSI Flanges

| DN \ Inch | A mm | B mm | H1 mm | H2 mm | C mm | D mm |
|-----------|------|------|-------|-------|------|------|
| 25 \ 1"   | 63   | 23   | 50    | 110   | 3    | 20   |
| 32 \ 1 ¼" | 73   | 28   | 50    | 120   | 3    | 25   |
| 40 \ 1 ½" | 83   | 34   | 54    | 140   | 3    | 40   |
| 50 \ 2"   | 102  | 44   | 64    | 180   | 3    | 40   |
| 65 \ 2 ½" | 121  | 59   | 76    | 200   | 3    | 40   |
| 80 \ 3"   | 131  | 70   | 100   | 230   | 3    | 65   |
| 100 \ 4"  | 162  | 92   | 127   | 260   | 3    | 70   |
| 125 \ 5"  | 192  | 118  | 140   | 320   | 3    | 80   |
| 150 \ 6"  | 216  | 140  | 152   | 400   | 3    | 95   |
| 200 \ 8"  | 272  | 178  | 254   | 470   | 3    | 115  |
| 250 \ 10" | 328  | 244  | 330   | 520   | 3    | 130  |
| 300 \ 12" | 378  | 295  | 390   | 600   | 3    | 170  |
| 350 \ 14" | 438  | 321  | 450   | 680   | 5    | 180  |
| 400 \ 16" | 489  | 368  | 500   | 780   | 5    | 200  |
| 450 \ 18" | 550  | 442  | 550   | 900   | 5    | 215  |
| 500 \ 20" | 599  | 465  | 550   | 1000  | 5    | 250  |

